

Ki-tec

Flyscreens



Self-closing Ki-tec® flyscreen for KULBA Teardrop



Closes automatically because of integrated magnets



Keeps insects where they are needed: outside



Fine-meshed 'outdoor mesh' keeps out small insects such as sand flies and midges



Easy to attach and detach

SUITABLE FOR:
- KULBA Woody
- KULBA Rebel

ALSO AVAILABLE:

- Ki-tec® magnetic flyscreens for (French) doors, sliding doors, camper and caravan doors
- Ki-tec® magnetic flyscreens for windows and tilting windows

DIMENSIONS

_____ (W) x _____ (L) cm

NUMBER

1 piece 2 pieces (set)



EAN 8721161777205
Type: KDCKUL01

Keep insects out... and enjoy your holiday!

MOUNTING Ki-tec® flyscreen for KULBA Teardrop

Here's how to attach the flyscreen with Velcro next to and above the rubber of the door:

1 Clean the wall.

- Thoroughly clean and degrease the inner wall around the rubber with ammonia and allow to dry.

2 Mark where the Velcro should go.

- Mark the width of the flyscreen both on the left and right side on the wall.
- Do this in several places and draw a vertical pencil line along those points on both sides.
- Mark the height of the flyscreen (98 cm) above the door.
- Measure from bottom to top. Start just above the bottom rubber edge so that the curtain will not touch the edge.

3 Stick the Velcro to the wall.

- Cut the Velcro for above the door to size.
- Remove the Velcro protective foil and stick the Velcro along the pencil line above the door. Press the Velcro firmly.
- Stick the Velcro tape both left and right to the wall. Leave the Velcro on the roll and cut it off at the bottom. Press the Velcro firmly.
- Does a control panel prevent you from sticking the Velcro to the wall? Then stick the Velcro against the panel.

4 Hang flyscreen.

- Press the top of the flyscreen against the Velcro. Make sure the bottom does not get stuck behind the bottom rubber edge.
- If necessary, hang the flyscreen slightly higher or lower.

5 All set!


Enjoy the fresh air in your KULBA, without insects. The curtain can simply remain hanging, even while driving.

PACKAGE CONTENT

- 1 or 2 Ki-tec® KULBA flyscreens
- White Velcro

REQUIRED TOOLS

- Pencil
- Measuring tape
- Ammonia
- Clean cloth
- Scissors



TIP

The doorway is often lower than the mattress. As a result, the curtain can get stuck behind the mattress when going in and out. You can use the extra Velcro tape to stick one or more extra strips above the door to easily hang the curtain higher or lower.

Keep insects out... and enjoy your holiday!